

Universal Replacement Latching Solenoid Pack

*The reCOIL DC-latching replacement solenoid
can be used with wide range of valve brands.
Easy to replace, fits in minutes!*


Features

- Universal DC-latching solenoid with thread adapters
- Floating plunger
- Heavy duty metal coil, low power draw
- Durability and longer life of the coil
- Easy removal replacement
- Efficiency, reliability, durable design
- Compatible with most popular brands including Rainbird, Irritrol, Hunter, Richdel and Bermad valves.
- 1 year warranty

Kit Includes:

- 1 x reCOIL DC-latching Heavy Duty Solenoid
- 3 x Thread Adaptors (Hunter®, Rainbird® & Irritrol®)
- 2 x Dryconn Black/Gray cable connectors

Part Number: RC12L




reCOIL RC12L Technical Information

- Power input 9-12VDC
- Resistance 5Ω
- Pulse on/Pulse off



How To Replace An Irrigation Solenoid

1. **TURN OFF** – Ensure the water and power supply are isolated
2. **REMOVE** - Unscrew the faulty solenoid coil
3. **REPLACE** – Select the correct adaptor and screw in the new reCOIL solenoid.
4. **RECONNECT** - Connect the wires using the connectors supplied, one wire to the common cable and one to the valve station cable.



How To use Dryconn Cable Connectors

1. Ensure the power is disconnected.
2. Strip wires to 10mm.
3. Align any frayed strands or conductors.
4. Pre-twisting unnecessary. Place stripped wires together with ends of insulation even.
5. Twist connector onto wires pushing firmly until hand-tight. Do not over tighten.
6. Wipe sealant in and around conductors and connector opening while tightening.



Do not reuse connector.

For more information visit
www.tonick.com